# **Instructions for Stool Collection**

### PART 1: THE DAY YOU RECEIVE YOUR KIT

- Complete the content checklist to ensure you have all items.
- Store the ice pack in your freezer.

### PART 2: THE DAY YOU COLLECT YOUR STOOL SAMPLE

Wait until your Data Collection Site visit is booked before collecting the sample. Take the sample no more than 4 days before your visit to the Data Collection Site.

#### STEP 1: READ instructions for

- Collecting the stool specimen: See Instructions for Use Stool Hat
- Using the collection tubes: See OMNImet-GUT tube (with red illustrations)

Note: instructions are identical for the OMNIgene-GUT tube instructions (with purple illustrations)

#### STEP 2: COLLECT stool into tubes.

\*Use sample from only one bowel movement for both tubes.

\*SHAKE the sealed tubes VIGOROUSLY for 30 seconds or longer to mix the sample with the preservative.

Clean the exterior of the tubes with the alcohol pad.

### RECORD information on the biohazard bag (white labels) using a pen: STEP 3:

- Date and time of sample collection.
- Check the box confirming BOTH tubes have been well mixed.

#### STEP 4: PACKAGE the tubes.

Place the two tubes in the biohazard bag and seal. Insert the biohazard bag into the thermal envelope. DO NOT SEAL. Store the envelope at room temperature. DO NOT FREEZE.

## PART 3: THE DAY OF YOUR DATA COLLECTION SITE VISIT

- Place the ice pack into the thermal envelope and seal it.
- Take the thermal bag with you to your visit.

If you require assistance, please contact us:







